

# QWIZDOM Q2 REMOTE

**Right/Wrong feedback** indicates the submitted response is correct (✓), incorrect (X), or received (✓ X).

**E-ink display** shows remote number, log-in, and answer info based on mode.

**Left/Right arrows** scroll through questions in paper-based mode, and left arrow is used as a backspace.

**Battery** indicates battery charge when remote is on.

**Network/Key Press indicator** is lit when remote is searching for the network, or an answer has been submitted.

**Log-on indicator** is lit while remote is in log-in mode.

**Remote indicator** is lit when the remote number is displayed.

**Question indicator** is lit when the question number is displayed in the paper-based mode.

**Power/Send** turns remote on/off, and submits user or session ID.

**Help/Select** is pressed to request assistance, and select menu options.

**Keypad** is used to answer Multiple Choice, True/False, Yes/No, Rating Scale, & Numeric questions.

